

# Audio Remote Code List

Maker (Brand) Name	Code Number (4 digit) List										
ADC	1007										
ADCOM	1057	1082	1092	1161	1225						
AIWA	1015	1104	1170	1202	1203	1213	1240	1241	1252		
AKAI	1138	1189									
AMC	1125	1126	1127	1171							
AMEND	1054										
ANAM	1248	1254									
ANGSTROM	1142										
ARCAM	1141										
AUDIO ACCESS	1147										
AUDIO FILE	1071										
AUDIO MATRIX	1167										
AUDIO TECHNICA	1134										
B & K	1096	1097									
BOSE	1070	1170	1224								
CARVER	1006	1013	1028	1061	1071	1077	1185	1201	1214	1226	
CASIO	1076										
CINEMA SOUND	1001	1134									
CITATION	1122										
CLARION	1026										
CURTIS MATHES	1076										
DENON	1001	1087	1109	1234							
ELNLIGHTENED AUDIO	1098										
ELTA	1216										
ELYXIO	1253	1255									
FISHER	1066	1214									
FOSGATE	1062	1122									
GOLDSTAR (LG)	1037	1008	1248								
GOODMANS	1254										
GRUNDIG	1123	1128	1133	1214	1248	1249					
HAL	1005										
HARMAN KARDON	1003	1118	1227	1122	1238	1245					
HITACHI	1020										
INKEL	1221	1222									

## Audio Remote Code List cont.

Maker (Brand) Name	Code Number (4 digit) List											
INTEGRA	1002											
JBL	1238											
JCPENNY	1076	1216										
JVC	1056	1114	1149	1163								
KENWOOD	1026	1066	1145	1146	1192	1199	1221	1222				
KOSS	1216											
KRELL	1072											
KYOCERA	1007											
LEXICON	1120	1180	1194									
LINN	1124											
LUXMAN	1004	1009	1052	1115	1139	1165						
LXI	1076											
MAGNAVOX	1086	1152	1164	1208								
MARANTZ	1006	1025	1028	1031	1040	1054	1063	1113	1185	1214	1247	
MCINTOSH	1178											
MCS	1076											
MERIDIAN	1012	1013	1100	1247								
MITSUBISHI	1153	1204										
MONDIAL	1042	1043	1081	1112	1157	1158						
NAD	1113											
NAKAMICHI	1040	1103	1150	1172	1183							
ONKYO	1002	1017	1046	1079	1090	1107	1108	1130	1179	1209		
OPTIMUS	1026	1041	1138									
PANASONIC	1195	1223	1237	1250	1251							
PHILIPS	1045	1047	1025	1034	1038	1063	1247					
PIONEER	1014	1026	1033	1035	1039	1044	1069	1078	1116	1168	1198	
	1220	1247										
PROCEED	1135	1144										
RCA	1010	1048	1067	1117	1156							
REALISTIC	1019	1056	1073	1075	1095							
ROTEL	1074	1083	1085									
SAMSUNG	1032	1050	1016	1249								
SANSUI	1040	1048	1063	1065	1110	1228						
SANYO	1214	1230										
SCOTT	1019	1091										
SEARS	1076											
SHARP	1026	1094	1175									
SHERWOOD	1024	1030	1051									
SONY	1011	1029	1015	1053	1064	1088	1101	1136	1184	1193	1218	
	1241	1240										
SOUNDESIGN	1036											
SSI	1068											
TAEKWANG	1138											
TEAC	1019	1040	1049	1212	1217							
TECHNICS	1214	1223	1245	1250	1251							
THORN	1216											
TOSHIBA	1060	1140	1198									
UNIVERSUM	1248	1249	1254									
YAMAHA	1018	1021	1022	1023	1026	1067	1089	1129	1169	1173	1177	
	1197	1200	1232									
ZENITH	1143	1210	1248									